


Earthwork for separate sides of the baseline

Instructions for calculating earthwork for a left or right side of the project separately




How to create Cross Sections

1. See workflow chart "Creating Cross Sections"

2. Create a cross section model for the left side

3. Create a cross section model for the right side

1. Open the Annotate tool



3. Load Preferences

